Locomansounds Class 20 Diesel Function List

Doehler & Haass

	With engine on	With engine off	When Moving	Stationary	Random	Volume CV		Volume CV	
F0	**Directional Lights**								
F1	**Stop/Start Diesel Engine**					**331**			
F2	**High Horn** Playable (direction dependent)					**335**	**Horn Nose**	**337**	**Horn Cab**
F3	**Low Horn** Playable **(direction dependent)**					**336**	**Horn Nose**	**347**	**Horn Cab**
F4	**Warning Horn** (direction dependent)					**339**	**Horn Nose**	**345**	**Horn Cab**
F5			**Manual Brake Application**			**338**			
F6				**Coupling Hook /** Aux 6					
F7			**Flange Squeal**	**Coach Door / Despatch Whistle**		**341/342**			
F8	**Heavy Train Acceleration**								
F9	**Spirax Valves**	**Spirax Valves**	**Spirax Valves**	**Spirax Valves**		**346**			
F10		**Electric Priming Pump**				**348**			
F11			**Buffer Clashes**			**344**			
F12	**Automatic Radiator Fan /Aux3**				**X**	**343**			
F13		**Forced Cold Start**	**Coasting**						
F14	**Compressor**				**X**	**340**			
F15	**No Brake Sound**								
F16	**Sound Fader Out**								
F17			**Automatic Coasting in Shunting Mode**						
F18			**Momentum Off**						
F19	**Aux 1**								
F20	**Aux 2**								
F21	**Volume Down**								
F22	**Volume Up**								
F23	**Aux 4**								
F24	**Aux 5/ Steam Generator**								