



Doehler & Haass

Class 37

In Cooperation with Digitrains

Function List

Locoman Sounds Mapping Scheme

D&H Decoder

F Key	Setting	Function/Sound	CV	Default
0	latch	Lights	-	-
1	latch	Engine on/off	331	150
2	momentary	Horn Lo (variable length)	336	167
3	momentary	Horn Hi (variable length)	335	170
4	optional	Brake Key	340 1 st Valve 334 Squeal	90 90
5	momentary	Brake Release	339	90
6	latch	Buffer up then Couple up	343	110
7	optional	Flange Squeal (variable length)	346	110
8	momentary	Lo Hi Horn	338	167
9	latch	Engine Idle	-	-
10	momentary	Hi Lo Horn	337	170
11	latch	Fan (also as a random sound)	342	80
12	optional	Coach Doors Slam (variable length)	347	130
13	optional	Primer	341	125
14	momentary	Guards whistle (variable length)	344	175
15	latch	Spirax	332 if Eng. off 348 if Eng. On	50 75
16	latch	Cab Door open then close	345	170
17	latch	Shunting Mode	-	-
18	latch	Aux 1 & Aux 2 Direction dependent & Auto Switchoff	Funct. CV 147 Funct. CV 148	139 32
19	latch	Momentum off	-	-
20	momentary	Volume Control (loop, 16 steps)	330	160 StartVol



Doehler & Haass

Class 37

In Cooperation with Digitrains

Function List

Locoman Sounds Mapping Scheme

D&H Decoder

F Key	Setting	Function/Sound	CV	Default
21	latch	Fade all Sounds	349	0 (Minimum)
22	latch	no Brake Squeal	334	90
23-28	-	Reserved	-	-

Volume Setting