



## Quick start guide V5 Class A4 sound project by Locomansounds Feb 29, 2020

F1 sound on, and volume adjustment by doubleclick

F2 playable whistle
F3 other whistles
Set function keys to momentary

F4 brake button, also brake valves

<u>F5 stationary: arm drain cocks (short press), or disarm drain cocks (long press > 1 sec).</u>

Sound comes when the loco starts.

Set function key to momentary

F6 coal shovelling & Aux 1 (Aux 2 on L and XL decoder)

F7 stationary: guard's whistle
F7 when driving: curve squeal
Set function key to momentary

F8 heavy load simulation

F9 coasting sound / light engine

F10 injector

F11 blower intensity (doubleclick toggles)

**Set function key to momentary** 

F12 in shunting mode: cab door (open - close), in train mode: coach doors slam

F13 only in shunting mode: briefly: coupling / long: uncoupling

F14 brake button, also brake valves

F15 safety valve

F16 in shunting mode: coaling tower, in train mode: water fill

F17 shunting mode





## F18 disable brake squeal

F19 disable momentum

F20 Aux 2 (Seuthe smoker) (Aux 1 for the L and XL decoder)

F21 fade out sound

F22 reserved

F23 reserved

F24 brake button, also brake valves

F25 to F28 Aux 5 to Aux 8 if enabled