



## Locomansounds D&H Q class



Doehler & Haass

<b>F key</b>	<b>Function</b>	<b>Volume CV</b> (T= Timer CV)	<b>Default</b>
<b>F0</b>	Lights on if fitted		
<b>F1</b>	Sound on / hiss & blower	331 / 332	165 / 25
<b>F2</b>	Whistle playable	336	130
<b>F3</b>	Whistle short	335	150
<b>F4</b>	Active brake and 1st brake valve sound	337	95
<b>F5</b>	Open draincocks	338	170
<b>F6</b>	Whistle medium	339	175
<b>F7</b>	Guard / Flange squeal (stat. / moving)	340 / 345	170 / 135
<b>F8</b>	Buffer clashing and clanking (only when moving)	341	150
<b>F9</b>	Forced coasting sound		
<b>F10</b>	Coal shovelling & Aux 1 (Aux3*)	342	110
<b>F11</b>	Injector	343	110
<b>F12</b>	Coach doors (stationary)	344	120
<b>F13</b>	Coupler sound & Aux 6	333	240
<b>F14</b>	Whistle fancy	346	145
<b>F15</b>	Safety valve	347	200
<b>F16</b>	Water fill (stationary)	348	120
<b>F17</b>	Shunting mode w. auto coasting	T: 350	10
<b>F18</b>	Volume up	330	110
<b>F19</b>	Volume down	330	110
<b>F20</b>	Aux 2 smoke generator (Aux4*)		
<b>F21</b>	Momentum off		
<b>F22</b>	No brake squeal		
<b>F23</b>	Soundfader	T: 359	6
<b>F24</b>	Reserved		
<b>F25</b>	Aux 5 Reserved		
<b>F26</b>	Light Dimming if fitted		
<b>F27</b>	Reserved		
<b>F28</b>			
<b>F29</b>			
<b>F30</b>			
<b>F31</b>			
<b>F32</b>			
<b>Brake</b>	Brake squeal	334	105