



## Locomansounds D&H Terrier Class Function List Doehler & Haass

<b>F key</b>	<b>Function</b>	<b>Volume CV</b> (T= Timer CV)	<b>Default</b>
<b>F0</b>	Lights on if fitted		
<b>F1</b>	Sound on / hiss & blower	331 / 332	160 / 36
<b>F2</b>	Whistle long	336	120
<b>F3</b>	Whistle short	335	130
<b>F4</b>	Active brake and 1 <sup>st</sup> brake valve sound	337	70
<b>F5</b>	Open draincocks	338	165
<b>F6</b>	Whistle fancy	339	115
<b>F7</b>	Guard / Flange squeal (stat. / moving)	340 / 345	140 / 80
<b>F8</b>	Buffer clashing and clanking (only when moving)	341	175
<b>F9</b>	Forced coasting sound		
<b>F10</b>	Coal shovelling & Aux 1 (Aux3*)	342	135
<b>F11</b>	Injector	343	110
<b>F12</b>	Coach doors (stationary)	344	135
<b>F13</b>	Coupler sound & Aux 6	333	120
<b>F14</b>	Airpump	346	50
<b>F15</b>	Safety valve	347	170
<b>F16</b>	Water fill (stationary)	348	120
<b>F17</b>	Shunting mode w. auto coasting	T: 350	9
<b>F18</b>	Volume up	330	160
<b>F19</b>	Volume down	330	160
<b>F20</b>	Aux 2 smoke generator (Aux4*)		
<b>F21</b>	Momentum off		
<b>F22</b>	No brake squeal	T: 359	6
<b>F23</b>	Soundfader		
<b>F24</b>	Reserved		
<b>F25</b>	Aux 5		
<b>F26</b>	Reserved		
<b>F27</b>	Light Dimming if fitted		
<b>F28</b>	Reserved		
<b>F29</b>			
<b>F30</b>			
<b>F31</b>			
<b>F32</b>			
<b>Brake</b>	Brake squeal	334	100

\* Please note that due to the light weight of the smaller locomotives we will not be responsible for any lack of smooth run due to poor power pickup. This lack of power pick up does not reflect upon the high quality of our sound. If once the sound decoder would be fitted inside the model and the problem persists please check the model as the quality of our sound is not to blame.