



Bulletin: GWR King Class

Decoder type LokSound 5
Address 3
Manufacturer Locomansounds
Project number Class King 4.7.2
Project version 1811 2103 210 3

AUX 1 = firebox flicker (preset to LED)

AUX 2 = preset to Seuthe smoker

AUX 3 = uncoupler (mapped but not configured)

Key	Function	Sound slots	Volume CVs	Volume values
F0	Lights			
F1	Sound on/off and 6 steps of volume			
F2	Playable Whistle	3	275	120
F3	Whistles	16	379	120
F4	Active Brake	13	355	36
F5	Preset Drain Cocks			
F6	Coupling / Uncoupling w. Shuffle	7	307	112
F7	Stationary: Guards Whistle / Drive: Flange Squeal	10, 15	331, 371	112, 106
F8	Heavy Load			
F9	Coast Mode			
F10	Coal Shovelling	5	291	100
F11	Blower / Ejector control			
F12	Coach Doors	12	347	96
F13	Injector	20	411	104
F14	Active Brake	13	355	36
F15	Safety Valve	14	363	128
F16	Train Mode: Water Tower / Shunting Mode: Coal Tower	4, 19	283, 403	124, 96
F17	Light Engine & Shunting Mode	4, 7	283, 307	124, 112
F18	Disable Brake Sound			
F19	Disable Momentum			
F20	AUX2 [1]			
F21	Not in use			
F22	Expert Mode OFF			
F23	Not in use			
F24	Active Brake			
F25	Not in use			
F26	Not in use			

F27	Not in use			
F28	Not in use			
F29	Not in use			
F30	Not in use			
F31	Random sounds	32	507	0