



GWR Small Prairie 45xx

Function	Description	Volume Control CV
F0	Lights	-
F1	Sound on, smart firebox flicker on	Chuffs 259 & 267
F2	Whistle GWR Main (1 of 3 whistles CV162)	283
F3	Whistle GWR Shunt (1 of 2 whistles CV160)	275
F4	Active brake	293
F5	Draincocks	299
F6	Fancy Whistle	403
F7	Stationary: doors close and guard whistle / Move: flanges	Doors Guard W 315, Flange 355
F8	Buffer clash	323
F9	Forced coasting sound	Set through Chuffs
F10	Coal shovelling (smart firebox flicker on Aux 1)	331
F11	Injector	339
F12	Ejector	387
F13	Coupler sound	499
F14	Whistle with echo (1 of 5 whistles selectable with CV160)	363
F15	Safety valve	371
F16	Water fill (stationary)	379
F17	Shunting mode with auto-coasting	-
F18	vacuum destroy	483
F19	Volume control	63
F20	Seuthe Smoke Unit	-
F21	Momentum off	-
F22	No brake squeal	-
F23	Sound fader	-
F24	Forced heavy load chuffs	-

