



Locomansounds Adams T3 Function List

	Volume Control CV
F0 Lights -	
F1 Sound on, smart firebox flicker on Chuffs	259 & 267
F2 Playable whistle SR main, dual (with F12) or shunt (with F17)	283, 459, 475
F3 Short whistle SR main, dual (with F12) or shunt (with F17)	275, 315, 307
F4 Vacuum brake or Steam brake (with F17)	291, 411
F5 Draincocks	299
F6 Fancy Whistle (main, dual or shunt)	403
F7 Stationary: doors close and guard whistle /Move: flanges	315/355
F8 Buffer clash	323
F9 Forced coasting sound Set through Chuffs	
F10 Coal shovelling (smart firebox flicker on Aux 1)	331
F11 Injector	339
F12 Dual whistle select	
F13 Coupler sound	499
F14 Whistle with echo (main whistle echo)	395
F15 Safety valve	371
F16 Water fill (stationary)	379
F17 Shunting mode with auto-coasting (uses shunt whistle) -	
F18 vacuum destroy	483
F19 Volume control	63
F20 Big ejector	443
F21 Momentum off -	
F22 No brake squeal -	
F23 Sound fader -	
F24 Forced heavy load chuffs -	
F25 Seuthe Smoke Unit -	